Task 1.1

The ratio between up-and down-state

spin population follows Boltzman statistics.

$$\frac{h us}{Nods} = e^{-\frac{AE}{kBT}}$$

$$\frac{AE}{Nods} = \frac{h}{Nods} = e^{-\frac{AE}{kBT}}$$

$$\frac{3E}{Nods} = \frac{h}{Nods} = e^{-\frac{AE}{kBT}}$$

$$\frac{3E}{Nods} = \frac{h}{Nods} = \frac{3}{Nods} = \frac{930 \text{ k}}{Nods}$$


$$\frac{Nus}{Nods} = \frac{930 \text{ k}}{Nods} = \frac{9398}{Nods}$$

$$\frac{An}{n} = \frac{Nus - Nds}{Nus + nods} = \frac{9.888 \times 10^{-6}}{Nods}$$

Task 1.2

ullet Perform equal excitations of given flip angle heta at a given repetition time  $T_R$ 


T1 = 500, T2 = 50, angle\_flip =  $0.06 \times \pi$ , repetition time = 50, number of pulses = 50.




The result shows that the system always converges to a steady state, which keeps oscillating periodically because of repeated excitation.

Vary T1, T2 and the flip angle.

T1 = 100, T2 = 50, angle\_flip =  $0.06 \times \pi$ , repetition time = 50, number of pulses = 50.



T1 = 100, T2 = 50, angle\_flip =  $0.2 \times \pi$ , repetition time = 50, number of pulses = 50.



When we vary T1, T2 and the flip angle, we can find out that the time to converge and the magnitudes of oscillation will also vary a lot. They are important parameters which influence the periodic magnetization dynamics.

## Ernst angle

Calculate the optimum flip angle when Tr and T1 have been given.

Immediately after nth Tr:  $M_z = M_z(n)$ 

After RF flip of  $\Phi$  and spoiling:  $M_z = M_z(n)cos\Phi$ 

After T1 recovery:

$$M_z(n+1) = M_0 - [M_0 - M_z(n)\cos\Phi]e^{-T}$$

In equilibrium,  $M_z = M_z(n) = M_z(n+1)$ 

$$M_z(1 - \cos\Phi \times e^{-\frac{Tr}{T1}}) = M_0(1 - e^{-\frac{Tr}{T1}})$$

$$M_{z} = \frac{M_{0}(1 - e^{-\frac{Tr}{T1}})}{1 - \cos \Phi \times e^{-\frac{Tr}{T1}}}$$

Equilibrium transverse magnetization:


$$M_{\perp} = M_{z} = \frac{M_{0}(1 - e^{-\frac{Tr}{T1}})}{1 - \cos\phi \times e^{-\frac{Tr}{T1}}}$$

The maximum transvers magnetization can be reached when:


$$cos\Phi_E = e^{-\frac{Tr}{T1}}$$

$$\Phi_E = \arccos\left(e^{-\frac{Tr}{T1}}\right)$$

When T1 = 500, T2 = 50,  $\Phi_E$  = 25.1986°.



When  $\Phi_E$  = 10°:



We can find that the transverse magnetization all decreased when we change the flip angle to a larger one or a smaller one.